

Key Switch Control

The Axis EN control panel range supports direct installation of up to 8 individual key switches.

Applications

The Axis EN 1 loop permits 1 key-switch to be fitted, but the Axis EN 2 & 4 loop control panels allow a maximum of 8.

Features

- Enable/disable controls
- Group isolate to disable I/O across network
- For use to start/enable a class change
- Trapped and un-trapped key switches available
- Control of multi-sensor/device sensitivity mode change
- Simple to install and configure
- Trapped and Un-trapped key switches

Order Codes and Options

Mxp-511(F):	Access Enable Key Switch Assembly for MX-5000
Mxp-518-001(F):	Access Enable Key Switch Assembly for MX-5010/5020
Mxp-518-002(F):	Access Enable Key Switch Assembly for MX-5030
Mxp-516(F):	2-position Key Switch Assembly - Trapped
Mxp-517(F):	2-position Key Switch Assembly - Untrapped
Mxp-519(F):	2-position Key Switch Assembly (Momentary contact) - Trapped
Mxp-515(F):	3-position Key Switch Assembly - Untrapped (requires 2 inputs)
Mxp-515T(F):	3-position Key Switch Assembly - Trapped (Free in centre position)
Mxs-511-KEY	Spare MXP-511 Access Enable Key
Mxs-511:	Spare access enable Key Switch (Lorlin style)
Mxs-516:	Spare 2 position Key Switch - Trapped (Lorlin style)
Mxs-517:	Spare 2 position Key Switch - Un-Trapped (Lorlin style)

Compatibility

Can be used with all Axis EN control panels.

Limitations

If an on-board printer is fitted to the Axis EN 2 & 4 loop control panels then the maximum number of switches fitted is limited to 4. If the 3-position switch is fitted, then two programmable inputs must be available per switch.

[Check if this document is up to date](#) | [Give us feedback](#)

Advanced, The Bridges, Balliol Business Park, Newcastle upon Tyne, NE12 8EW, UK T: +44 (0)345 894 7000, E: enquiries@advancedco.com, W: www.advancedco.com

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.