

1-2 Loop Fire Alarm Control Panel

The MxPro 5 series control panels are fully expandable from 1 - 2 loops and supplied with 2 onboard sounder circuits, 20 programmable zonal LEDs with slide-in labels, and 25 system LEDs for information purposes. There are also 4 programmable function buttons with LED indication for confirmation of operation.

The control panel consists of the latest dual flash-based microprocessor technology combined with a high resolution, high contrast, graphical LCD display and tactile keypad providing a simple select and click programming aid for engineer configuration and end user operation.

Compatible with AdvancedLive (UK&I only), which is the fire panel monitoring solution that enables secure, easy, real-time management of your fire system.

Powerful cause-and-effect programming and enhanced trace diagnostics make the panel suitable for a wide range of site applications from small to large complex multi-area systems. Fully programmable onsite via the onboard alphanumeric keypad, or PC-NeT-022 configuration software.

PC Software: An extensive suite of user-friendly Windows-based PC software programs has been developed to enhance your experience when using MxPro 5 Series of Fire panels. The suite incorporates a number of different programmes to include a configuration, service and logo tool to allow greater flexibility of the equipment to be fully explored.

Network: Simply adding a network card allows the panel to communicate with any other MxPro 5 fire panel, remote terminal, or network peripheral, BMS or Graphical Interface. The network operates as a true peer-to-peer system and can be configured in a fault-tolerant loop or radial format.



Features

- Connectivity to AdvancedLive (UK&I only) , Ethernet connection on-board
- Apollo, Argus Vega, Hochiki & Nittan Evolution protocol support.
- Advanced graphical LCD user interface and support for up to 200 fire zones by default allowing full EN54 compliance without additional hardware.
- Dual flash-based microprocessor technology with real-time clock onboard.
- Dedicated USB & RS232 serial port for direct PC or modem connection.
- Installer friendly Auto-learn, Loop Detection and Onboard Scope facilities for ease of commissioning and fault finding.
- Graphical display configurable for virtually any language
- Robust removable equipment chassis with plug-in connectors for simple fixing and cable termination.
- Fully programmable via the onboard alphanumeric keypad, or PC configuration tools.
- Integral 'P-Bus' for system expansion via available option cards
- Advanced networking, peer-to-peer system, with up to 2000 zones
- Programmable push buttons
- Global compliance
- 3-year warranty
- Fully programmable
- Installer's logo application

Approvals



- EN 54-2:1997 +A1:2006
- EN 54-4:1997 +A1:2002 +A2:2006
- EN 54-13:2005 (Pending)

Certified to EN54 Parts 2 & 4 by FM Approvals

Specification

Base Technology	Dual flash-based processors with real-time clock, trace diagnostics, programmable languages and character sets
Display	White backlit 240 x 64 graphical LCD (5.5 inches x 2.5 inches)
LED Indicators	22 red (1 x Fire, 1 x More Alarms, 20 x Zonal Programmable), 1 green (Power), 13 amber and 12 bi-colour (Fault & System)
Controls Protocols	Alpha numeric keypad permitting Navigation, Reset, Mute, Silence, Resound, Evacuate, and 4 x programmable push buttons
Protocols	Apollo (Soteria / XP95 / Discovery), Argus Vega, Hochiki ESP
Number of Fire Zones	2000 (200 per individual panel)
Number of Loops	Dedicated 1-2 loop control panel
Devices per loop	Protocol dependent
Loop Current	500mA per loop
On-Board Sounder Circuits	2 x 1 Amp programmable
On-Board Relays	2 x 1 Amp 30v AC/DC programmable (10mA, 5v min) - expandable to 4 using MXP-507
Auxiliary Supply	1 x 24v 500mA
Programmable Input	1 x monitored programmable input on-board
Programmable Key Switch Inputs	8 volt free inputs
Total Available Output Current	5A maximum available for loop current + sounder outputs + auxiliary supply
Mains Supply	200 - 240v 50-60 Hz AC (+10%, -15% tolerance) 1.4A max
Charger Current	2A temperature compensated
Ethernet	10-Base-T, 100-Base-T: Providing AdvancedLive connectivity (UK&I only)
Serial ports	1 x On-board RS232 connection for PC, modem, IP, or portable printer
USB Interface	1 x USB B type connection for PC communication
Programming	On-board keypad or PC running Windows tools
Event Log	5000 event & diagnostic + 500 fire
Networking	Optional plug in Network Card (MXP-503 - Standard, or MXP-509 - Fault-Tolerant)
Enclosure / Colour	Steel IP30 / RAL7035
Temperature	-5°C to 40°C
Humidity (RH)	95% Max
Metalwork Options	Flushing bezel, battery box, utility enclosure and termination enclosure

Dimensions and Capacity

	Dimensions	Cable Entry	Battery Capacity (internal)	
	H x W x D mm	(20mm knockouts)	Min	Max
Standard	345 x 430 x 120	13 x top, 8 x rear	24v, 4Ah	24v, 12Ah
Large	475 x 450 x 120	19 x top, 11 x rear, 2 x bottom	24v, 4Ah	24v, 18Ah
Large-Deep	475 x 450 x 190	30 x top, 11 x rear, 3 x bottom	24v, 4Ah	24v, 45Ah

Order Codes and Options

Enclosure/Protocol	Apollo (XP95/Discovery) / Hochiki ESP	Apollo Soteria *	Argus Vega	Nittan Evolution
Standard	MX-5201	MX-5201A	MX-5201V	MX-5201N
Large	MX-5201L	MX-5201AL	MX-5201VL	MX-5201NL
Large-Deep	MX-5201D	MX-5201AD	MX-5201VD	MX-5201ND

*MXP-568 is required

Note: 1 loop card comes as standard. If more loops are required, please order 1 loop driver card per extra loop.

Part Code	Description
MXP-568	Loop driver card - Apollo, Hochiki, Argus Vega
MXP-567	Loop driver card - Nittan

[Check if this document is up to date](#) | [Give us feedback](#)

Advanced, The Bridges, Balliol Business Park, Newcastle upon Tyne, NE12 8EW, UK T: +44 (0)345 894 7000, E: enquiries@advancedco.com,
W: www.advancedco.com

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.